Maria Valencia

CSC 153

LAB 6

Lab 6: File Slack and Wiping


In this lab, I will complete two tasks inspired by the Hand-On Projects 6-2 and 6-3. The first task requires that I create a USB VHD and store secret data in the file slack of a sample file. The second task securely wipes that USB VHD created.

Task 1: File Slack


In this task I created a virtual device and attached it to my windows VM. The drive is used to host a file that I wrote additional data in its slack space using Hex Workshop.

Step 1: Create "USB" virtual drive


I launched the VM's settings in VirtualBox and selected storage. Selected "Controller:SATA" within the storage Devices section and pressed the add drive button.




Selected the Create Button.




Selected VHD and Next.




Selected Next on the Storage on physical hard disk step.




I changed the file name to "chapter6.vhd" and 10MBs and pressed Finish.



I selected the chapter6.vhd under "Not Attached" and then choose.




I observe that the drive is now attached to the VM. I pressed OK and then started the VM.




Step 2: Setup the "USB"


With the VHD attached and the windows VM booted, I launched the Disk Management app by searching "Create and format disk partitions".




When the Disk Management utility launched, I selected MBR and OK to the recommended prompt.




With disk 1 initialized, I right clicked the drive and selected New Simple Volume from the context menu.




Selecting New Simple Volume launches the Set up wizard. I followed the wizard use default options.




Once Completed, it shows a 7MB NTFS volume.




I opened File explorer and navigated to the E drive.



I right clicked in the open space drive, selected New and text document to create a new file. I named the file chapter 6.




I opened the chapter6 text file and filled it with 10000 capital A's. And the phrase "Forensics Rocks at the end. Then Save and close the text file.



Step 4: Install Hex Workshop


I opened a web browser and navigated to http://www.bpsoft.com/downloads/ and downloaded the latest version of Hex Workshop Hex Editor. (this was unavailable so I found a work-around)



Once it was downloaded, I went to my downloads folder and double clicked it to start the installation process. I accepted the UAC prompts.




Select next when the Hex Workshop installation wizard launches. Allow any older versions to be removed, accept the license agreement, and use the Typical setup type, then install. After a few seconds the installation should be complete. Select Finish and then reboot the Windows VM.



Step 5: Hide data in Slack Space


After the windows VM rebooted, I right-clicked the Hex Workshop Icon and ran as administrator to launch the application.




I opened the VHD/USB drive by selecting disk and then "Open Drive".




I chose the "New Volume (E:)" and pressed OK.




I observed the drives hexadecimal space is loaded with ASCII representation on the right column.




Pressing the blue right triangle will load the next sector in the drive. Alternatively, press "Alt+Dn" to go to the next sector as a shortcut key. Cycle through the sectors until you find the sector filled with "A"s which may be 100s of sectors away from the 1st sector of the drive.




I right-clicked the ASCII section, selected find and find again to open the search window.




I enter "Forensics" in the value and pressed OK to search for Forensics.




The file should have some empty bytes after "Forensics Rocks!" as highlighted in the following screenshot. This empty space is called file slack, where the content of the file does not completely feel the sector of the drive it resides in.



Click somewhere in the file slack space, with at least 5 characters of space to the right, and type the word "Secret". Observe the lettering is red, which indicates an unsaved change. Then save the file by pressing "Ctrl S", the save icon on the menu bar, or File -> Save. After saving the lettering becomes a black font.



Close Hex Workshop and open the chapter6.txt file. Navigate to the end of the last line where the "Forensics Rocks!" phrase is located. Observe the word "Secret" is not there!



Step 6: File Slack Explanation


"Secret" was not represented in the chapter6 txt file because when we first created and saved the chapter6 text file, we did not have it there. Since we added it on the hex editor and saved it on the hex editor, it will show up there and not the text file because the hex editor can build upon a text file but the text file itself cannot be changed within the hex editor. We can hide data this way because if there is something we do not want on the text file itself, we can add it on the hex editor where you will only be able to see it on there. So, if you sell your computer, you won't have to worry about sensitive information on the text files.

Task 2: Secure Wipe


In this task, I installed DBAN disk wiping utility and secure the "USB" drive created in the previous task.

Step1: Download and Setup DBAN


From my host machine, I navigate to https://sourceforge.net/projects/dban/ and download the ISO.




Now on your windows VM settings in virtual box, navigat eto storage. Select controller: SATA and press the add optical drive.




I pressed the Add button in the optical disk selector window.




I navigated to my downloads folder where the DBAN ISO file is located. Selected the ISO and pressed open.



Th ISO appears in the Not Attached section of the optical disk selector windows. I selected it and pressed choose.




The DBAN ISO now appears in the storage devices section.




Step 2: Boot to the DBAN ISO

With the VirtualBox VM settings open, I selected System and then chose "Optical" from the Boot Order section. I pressed the up-arrow icon to move Optical to the first position (top of the list). Then pressed OK.




DBAN was booted.

I closed the windows VM by selecting "Power Off" and then OK. With the VM powered down, I returned to the VirtualBox Windows VM settings, selecting Storage adn then removing the DBAN ISO attachment.




I then navigate to the windows VM settings for system and change the boot order back to having a hard disk at the top of the list.




Step 3: Investigate the drive


With the Windows VM started, I right clicked the Hex Workshop shortcut and ran as administrator.




I load the USB drive by navigating to Disk and Open Drive.



I select the 10MB drive and press OK.



I observe all sectors have no data!



Step 4: Research DBAN methods

Another method is the DoD 7-pass which overwrites data seven times: three passes of overwriting with different patterns followed by a verification pass. There's also the Gutmann Method which performs 35 passes of overwriting with a specific sequence of random and predefined patterns. Finally, there is the random data pass which overwrites the drive with random data in just a single pass. I believe from these three the most secure would be the DoD 7 pass since there's three passes of overwriting with different patterns followed by a verification pass and it is quicker than the Gutmann Method.